

# BLUEY

## HIDE & SEEK Game


### INSTRUCTIONS

**BE THE FIRST  
TO FIND BLUEY!**

### INCLUDES

- 1 Electronic Bluey
- 2 Try-Me AAA Batteries
- 1 Instruction Manual

Hide me!  
I talk &  
give  
clues!



PLAYERS


2+

AGES

3+

15 MINUTES

REQUIRES  
2 AAA  
BATTERIES



### ADDING BATTERIES

2x AAA 1.5V

TEMPORARY BATTERIES INCLUDED for try-me feature.  
REPLACEMENT BATTERIES NOT INCLUDED.  
Replace with 2 AAA batteries.

Refer to Battery Information sheet.

### FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. **CAUTION:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. **NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or experienced radio/TV technician for help. CAN ICES-003 (B) / NMB-003 (B)



Help the environment by disposing of your product and batteries responsibly. The wheellie bin symbol indicates that the product and batteries must not be disposed of in the domestic waste, as they contain substances which can be damaging to the environment and health. Please use designated collection points or recycling facilities when disposing of the item or batteries. More information can be found on: <http://www.recycle-more.co.uk> | [www.recyclenow.com](http://www.recyclenow.com)



**BBC  
STUDIOS**



BLUEY (word mark and character logos) are trade marks of Ludo Studio Pty Limited and are used under licence. BLUEY logo © Ludo Studio Pty Limited 2018. Licensed by BBC Studios. BBC is a trade mark of the British Broadcasting Corporation and is used under licence. BBC logo © BBC 1996



### WARNING:


CHOKING HAZARD - Small parts.  
Not for children under 3 years.





## GETTING STARTED

- Flip the switch on Bluey to the ON position.



- The person that is the best dancer is the first to hide Bluey! This will be the "Hider". All other players are the "Seekers".



## HOW TO PLAY

### HIDING BLUEY

- The Hider hides Bluey in the sneakiest hiding spot.
- While Bluey is being hidden, the Seekers must close their eyes and count to 20. No peeking!
- Once hidden, press Bluey's nose to start the timer. Return to the Seekers and let them know they can start looking for Bluey!

### FINDING BLUEY

- All Seekers begin looking for Bluey once they finish counting.
- Bluey will begin talking and giving clues to help the Seekers find her.
- The first Seeker to find Bluey is the winner! Press Bluey's nose to play Dance Mode and have a dance party!

The Seeker that found Bluey is now the Hider! Find a new hiding spot and press her nose to start the game again!


When play is finished, flip the switch on Bluey's back to OFF position.




### HIDDEN CHATTERMAX

Silly Chattermax is trying to distract you with his own game of Hide & Seek! Can you find all the Chattermax's hidden around the package?

**WARNING:** NOT SUITABLE FOR CHILDREN UNDER 3 YEARS.  
**CAUTION:** ADULT SUPERVISION ENCOURAGED FOR YOUNG CHILDREN. **IMPORTANT:** PLEASE RETAIN INSTRUCTION DETAILS FOR FUTURE REFERENCE. COLORS AND CONTENTS MAY VARY.



18983-00/03/11-R0



www.moosetoys.com

2024 The Moose Group